

Polyethylene, acid copolymer and ionomer sealants on aluminium foil - What really makes them different?

Guenter Schubert and André Lehnhardt



HYDRO

Hydro Aluminium Rolled Products GmbH
R&D Bonn, Germany

Presented by:

Guenter Schubert






Structure

- ✧ **Laminates for hot tack comparison**
- ✧ **Rheometer methods**
 - ✧ **Viscosity curves**
 - ✧ **Temperature sweeps**
 - ✧ **Temperature/melt tack measurements**
- ✧ **Advanced hot tack method**
- ✧ **Interfacial temperature during hot tack**
- ✧ **Correlation hot tack, real temperature and viscosity**
- ✧ **Summary**

Structure

- ✧ **Laminates for hot tack comparison**
- ✧ **Rheometer methods**
 - ✧ **Viscosity curves**
 - ✧ **Temperature sweeps**
 - ✧ **Temperature/melt tack measurements**
- ✧ **Advanced hot tack method**
- ✧ **Interfacial temperature during hot tack**
- ✧ **Correlation hot tack, real temperature and viscosity**
- ✧ **Summary**

Compared laminates with ionomer sealants



Laminates with ionomer, PE and acid copolymer

PET	12 µm
Adhesive	
Aluminium	9 µm
Adhesive	
Ionomer MI 14	50 µm

PET	12 µm
Adhesive	
Aluminium	9 µm
Adhesive	
Ionomer MI 5	50 µm

PET	12 µm
Adhesive	
Aluminium	9 µm
EMAA (8%)	5 g/m²
LDPE 1	40 g/m²
(LDPE 18R430 MI 14)	


PET	12 µm
Adhesive	
Aluminium	9 µm
EMAA (8%)	5 g/m²
LDPE 2	40 g/m²
(LDPE 23L430 MI 5)	

PET	12 µm
Adhesive	
Aluminium	9 µm
EMAA (8%)	5 g/m²
EMAA (8%)	40 g/m²
(EMAA 28M430 MI 8)	


Structure

- ✧ Laminates for hot tack comparison
- ✧ Rheometer methods
 - ✧ Viscosity curves
 - ✧ Temperature sweeps
 - ✧ Temperature/melt tack measurements
- ✧ Advanced hot tack method
- ✧ Interfacial temperature during hot tack
- ✧ Correlation hot tack, real temperature and viscosity
- ✧ Summary


Viscosity curves of LDPE (MI 14) between 190°C and 110°C



Viscosity curves of EMAA (MI 8) between 190°C and 110°C




Viscosity curves of ionomer (MI 14) between 190°C and 110°C




Structure

- ✧ Laminates for hot tack comparison
- ✧ Rheometer methods
 - ✧ Viscosity curves
 - ✧ Temperature sweeps
 - ✧ Temperature/melt tack measurements
- ✧ Advanced hot tack method
- ✧ Interfacial temperature during hot tack
- ✧ Correlation hot tack, real temperature and viscosity
- ✧ Summary


Temperature sweep of an LDPE (MI 5)




Temperature sweep of an LDPE extrusion coating grade (MI 5, ρ 0.923)




Temperature sweep of LDPE coating grades (MI 5, ρ 0.923 and MI 14, ρ 0.918)




Temperature sweep of LDPE coating grades (MI 5 and MI 14) and EMAA 8% (MI 8)




Temperature sweep of LDPE (MI 14, ρ 0.918) and ionomer (MI 14, ρ 0.938)




Temperature sweep of LDPE (MI 5, ρ 0.923) and ionomer (MI 5, ρ 0.939)




Temperature sweep of LDPE (MI 14, ρ 0.918), ionomer (MI 14, ρ 0.939) and EMAA (MI 8, ρ 0.938)



Temperature sweep of LDPE and ionomer (both MI 5) and an acid copolymer (MI 8)



Temperature sweep of LDPE and ionomer (both MI 5) and an acid copolymer (MI 8)



Structure

- ✧ Laminates for hot tack comparison
- ✧ Rheometer methods
 - ✧ Viscosity curves
 - ✧ Temperature sweeps
 - ✧ **Temperature/melt tack measurements**
- ✧ Advanced hot tack method
- ✧ Interfacial temperature during hot tack
- ✧ Correlation hot tack, real temperature and viscosity
- ✧ Summary

Melt tack procedure in principle

Principle:

Lifting the upper geometry, here plate with a constant speed


Monitoring the normal force along with the plate/plate distance at constant temperature

Plate $D = 8 \text{ mm}$


Initial gap = 0.4 mm

Final gap = 2 mm

Repeat the measurement in the desired temperature range




Melt tack sample after elongation at the final gap




*** Plate/plate rheometer with melt**


Comparison of the melt tack curve of ionomer (MI 14) and LDPE (MI 14) at 190°C



Comparison of the melt tack curve of ionomer (MI 14) and LDPE (MI 14) at 120°C




Comparison of the melt tack maxima between 190°C and 90°C




Structure

- ✧ Laminates for hot tack comparison
- ✧ Rheometer methods
 - ✧ Viscosity curves
 - ✧ Temperature sweeps
 - ✧ Temperature/melt tack measurements
- ✧ **Advanced hot tack method**
- ✧ Interfacial temperature during hot tack
- ✧ Correlation hot tack, real temperature and viscosity
- ✧ Summary


Hot tack peeling conditions




Hot tack curves of different sealants in aluminium laminates (120°C - 1s - 0.167 MPa)



Hot tack curves (detail) of different sealants in aluminium laminates (120°C - 1s - 0.167 MPa)




Sealing geometry for hot tack measurement - Strip is wider than the jaws – Lateral cooling



Top view

Lateral cooling (edge effect), similar to situation in a packaging machine




Side view


Structure

- ✧ Laminates for hot tack comparison
- ✧ Rheometer methods
 - ✧ Viscosity curves
 - ✧ Temperature sweeps
 - ✧ Temperature/melt tack measurements
- ✧ Advanced hot tack method
- ✧ **Interfacial temperature during hot tack**
- ✧ Correlation hot tack, real temperature and viscosity
- ✧ Summary

Sealing geometry for hot tack measurement – Positioning of thermocouples





Top view




Side view

Thermocouple wire - Embedded in a seal seam






Side view


Sealing geometry for hot tack measurement – Positioning of thermocouples




Top view




Course of the interfacial temperature at different positions in the seal seam – PET 12 μm /ionomer(MI 5) 50 μm - 135 $^{\circ}\text{C}$ – 1 s




Course of the interfacial temperature at different positions in the seal seam – PET 12 μ m/**Al 9 μ m**/ionomer(MI 5) 50 μ m - 135°C - 1s



Secondary sealing edge effect in a seal seam*




Secondary sealing edge effect in a seal seam*




Structure

- ✧ Laminates for hot tack comparison
- ✧ Rheometer methods
 - ✧ Viscosity curves
 - ✧ Temperature sweeps
 - ✧ Temperature/melt tack measurements
- ✧ Advanced hot tack method
- ✧ Interfacial temperature during hot tack
- ✧ **Correlation hot tack, real temperature and viscosity**
- ✧ Summary


Hot tack curves at: target temperature, real sealing temperature and actual temperature of hot tack measurement




Hot tack curves at: target temperature, real sealing temperature and actual temperature of hot tack measurement



Interfacial temperatures, associated viscosities - for melt entangling and disentangling - related to hot tack - PET/ionomer MI 5



Interfacial temperatures, associated viscosities - for melt entangling and disentangling - and related hot tack - PET/Al/ionomer MI5



Structure

- ✧ Laminates for hot tack comparison
- ✧ Rheometer methods
 - ✧ Viscosity curves
 - ✧ Temperature sweeps
 - ✧ Temperature/melt tack measurements
- ✧ Advanced hot tack method
- ✧ Interfacial temperature during hot tack
- ✧ Correlation hot tack, real temperature and viscosity
- ✧ Summary

Summary

- **Ionomers and EMAA show a much more pronounced temperature dependent viscosity increase than LDPE, starting at 190°C to typical sealing temperatures, as indicated by melt tack and viscosity curves at the relevant temperature and by temperature sweeps following the solidification and melting behaviour of the sealants.**
- **True interfacial temperatures at different positions of the seal seam, under the same conditions as the hot tack measurement, have been monitored.**
- **Seal seams are not as homogeneous in temperature as commonly thought. A hot tack measurement does not take place at a constant and single temperature, but in a time- and location dependent temperature range or profile.**
- **Aluminium laminates enhance the hot tack generally, also for high performance ionomer sealants, not only by lateral cooling effect on the seal seam,**
- **But also by secondary sealing which means an increase of the seal seam width**

Acknowledgements

We thank

Jacques Roulin, Dupont CH, for providing ionomers and their films,

Marcus Pisanec, Michael Reynolds and their Henkel Liofol pilot line team for laminating,

Petra Hollacher and her INEOS pilot line team for preparing the extrusion coatings,

our Hydro Aluminium colleagues

Petra Zaied and Heidi Paeseler for their detailed metallographic work,

Michael Lennarz and Marc Seidel for their great assistance in measurement technology,

Dieter Zimmermann and Lukas Peters for their proper work in mechanical construction,

Kai Karhausen and Simon Jupp for intellectual discussions and Marcus Eue for proof-reading.

**Thank You
for sticking again with me...**

**Remember, when measuring hot tack,
what you see is not always what you get!**

Presented by:

Guenter Schubert

- Foil Converting -

Hydro Aluminium Rolled Products GmbH, R&D Bonn

guenter.schubert@hydro.com

