

PLACE 2016

EXPLORING
NEW FRONTIERS

April 11-13 2016
FORT WORTH TEXAS

Grease Resistant Multilayer Polyethylene Films

Presented by:
Shivendra Goyal
Principal Engineer

Centre for Applied Research
NOVA Chemicals Corporation
Calgary, Alberta
Canada



Outline

- Background and introduction
- Grease resistance method development
- Grease barrier studies:
 - **Screening** experiments – Multi-material films
 - **Validation** of results – 3 layer all-PE films
 - **Real world** designs – 9 layer all-PE films
- Summary and conclusions



Background

- **Significant growth in flexible packaging** of grease-containing materials that were traditionally packaged in:
 - metal cans
 - glass bottles
 - rigid plastic containers
- Factors driving conversion
 - Supply chain and package **cost reduction**
 - **Sustainability** improvements
 - Consumer **convenience**

Progression of Grease Barrier Packaging



*Photo credit Robert Kneschke

The Challenge


- Develop “*All PE*” film structures that provide:
 - ✓ Good grease resistance
 - ✓ Desired film properties
 - ✓ Improved sealability
 - ✓ Excellent processability
 - ✓ Recyclability of packaging after its intended use; and
 - ✓ Cost effective solutions

Grease Resistance Measurement

Semi-Quantitative Test Method Development


The Modified Method

Test description	<ul style="list-style-type: none">• Fat source placed on test film that is positioned on a TLC plate• 2 kg weight placed on fat source and assembly put in a oven• After 48h, TLC plate inspected and photographed under UV light
Measurement	<ul style="list-style-type: none">• Area of grease penetration
Benefits	<ul style="list-style-type: none">• Simple and clear detection system• Enables quantification of grease penetration (stain area)• Repeatable and Reproducible




Based on original method developed by Wyser *et al*, Nestlé Research Center, TAPPI PLACE 2002 Conference

Grease Barrier Measurement Set-Up




Quantification of Results

Use of ImageJ software*




Photograph under
254 nm UV light

Convert to 8
bit black and
white image



Process





Select best
representation
and count
pixels

Obtain "area fraction",
percent of dark pixels

e.g. 28 %

* ImageJ is a public domain, Java-based image processing program

Application of Results: Breakthrough Profile



Grease Barrier Studies

Study #1 – Multi-material Screening

Non-PE Resins

Resin Code	Resin Type	Melt Index (dg/min)	Density (g/cc)
EVOH	Ethylene Vinyl Alcohol Copolymer	1.7	1.17
Tie Resin	Maleic Anhydride Modified LLDPE	N/A	N/A
EAA	Ethylene Acrylic Acid Copolymer	1.0	0.938
Ionomer	Zn Ionomer	1.8	0.940

All PE Resins

Resin Code	Resin Type	Resin Name	Melt Index (dg/min)	Density (g/cc)
sLLDPE	Single Site Octene LLDPE	SURPASS® FPs016-C	0.65	0.916
sHDPE	Single Site Bimodal HDPE	SURPASS® HPs167-AB	1.20	0.966
HDPE-1	Z-N HDPE	SCLAIR® 19C	0.95	0.958
HDPE-2	Z-N HDPE	SCLAIR® 19G	1.20	0.960
o-LLD	Z-N Octene LLDPE	SCLAIR® FP120-D	1.0	0.920
o-VLD	Z-N Octene VLDPE	SCLAIR® FP112-A	0.90	0.912

SURPASS® and SCLAIR® are registered trademarks of NOVA Chemicals Corporation in Canada and of NOVA Chemicals (International) S.A. elsewhere


Study #1 – 9 Layer Film Construction

	Film Names	A	B	C	D	Middle	F	G	H	I
EVOH	EVOH/ o-LLD	sLLDPE	o-LLD	o-LLD	Tie Resin	EVOH	Tie Resin	o-LLD	o-LLD	o-LLD
	EVOH/sHDPE	sLLDPE	sHDPE	sHDPE	Tie Resin	EVOH	Tie Resin	sHDPE	sHDPE	o-LLD
sHDPE	EAA/sHDPE	sLLDPE	sHDPE	sHDPE	EAA	EAA	EAA	sHDPE	sHDPE	o-LLD
	Ionomer/sHDPE	sLLDPE	sHDPE	sHDPE	Ionomer	Ionomer	Ionomer	sHDPE	sHDPE	o-LLD
Conventional HDPE	EAA/ HDPE-1	sLLDPE	HDPE-1	HDPE-1	EAA	EAA	EAA	HDPE-1	HDPE-1	o-LLD
	Ionomer /HDPE-1	sLLDPE	HDPE-1	HDPE-1	Ionomer	Ionomer	Ionomer	HDPE-1	HDPE-1	o-LLD
No HDPE	EAA / o-LLD	sLLDPE	o-LLD	o-LLD	EAA	EAA	EAA	o-LLD	o-LLD	o-LLD
	Ionomer / o-LLD	sLLDPE	o-LLD	o-LLD	Ionomer	Ionomer	Ionomer	o-LLD	o-LLD	o-LLD
	o-LLD/o-LLD	sLLDPE	o-LLD	o-LLD	o-LLD	o-LLD	o-LLD	o-LLD	o-LLD	o-LLD

Study#1 Results: Grease Breakthrough

		Grease Breakthrough Values %				
	Oven Temperature (°C):	70	60	50	40	Grease Resistance
EVOH	EVOH/o-LLD	1				✓
	EVOH/sHDPE	4				✓
sHDPE	EAA /sHDPE	4	1	0	0	✓
	Ionomer /sHDPE	16				✓
Conventional HDPE	EAA /HDPE-1	25	0	0	0	X
	Ionomer /HDPE-1	26				X
No HDPE	EAA /o-LLD	44				X
	Ionomer / o-LLD	60				X
	o-LLD/o-LLD	45	20	12	0	X

Study#1 Results: Grease Breakthrough Profiles




Study#1 Conclusion:
sHDPE provides excellent grease resistance performance

Study #2 – Validation of Results: 3 – layer all PE films

Film Type	A (25%)	B (50%)	C (25%)
Single site sHDPE in core	o-LLD	sHDPE	o-LLD
Conventional HDPE in core	o-LLD	HDPE-2	o-LLD
No HDPE in core	o-LLD	o-LLD	o-LLD

Study#2 Results: Grease Breakthrough Profiles




Study#2 Conclusion:
Excellent grease barrier performance of sHDPE in 3 layer all PE films

Study#3: Innovative film structure designs

All PE 9 layer films

Film Structure	A	B	C	D	Middle	F	G	H	I
EVOH Benchmark	o-LLD	o-LLD	o-LLD	Tie Resin	EVOH	Tie Resin	o-LLD	o-LLD	o-VLD
3 layers of sHDPE + sLLDPE	o-LLD	sHDPE	sLLDPE	sLLDPE	sHDPE	sLLDPE	sLLDPE	sHDPE	o-VLD
2 layers of sHDPE + sLLDPE	o-LLD	sHDPE	sLLDPE	sLLDPE	sLLDPE	sLLDPE	sLLDPE	sHDPE	o-VLD
2 layers of sHDPE + ZN o-LLD	o-LLD	sHDPE	o-LLD	o-LLD	o-LLD	o-LLD	o-LLD	sHDPE	o-VLD

Study#3 Results: Grease Breakthrough Profiles



Study#3 Conclusions:

Equivalent Grease Barrier performance of sHDPE containing films vs. EVOH benchmark film

Physical Properties of All PE 9-Layer Films

Film Structure/Property	EVOH Benchmark	3 layers of sHDPE + sLLDPE	2 layers of sHDPE + sLLDPE	2 layers of sHDPE + ZN o-LLD
1% Secant Modulus - MD (MPa)	417	543	422	449
1% Secant Modulus - TD (MPa)	433	599	470	500
Tensile Yield Strength - MD (MPa)	14.5	16.9	14.4	15
Tensile Yield Strength - TD (MPa)	14.4	17.7	15.1	16
Dart Impact (g)	738	1008	1056	960
Puncture (J/mm)	53	77	74	70
Elmendorf Tear - MD (g)	1242	1224	1788	1914
Elmendorf Tear - TD (g)	2070	1824	2376	2916

Study#3 Conclusion:

Higher film physical properties (stiffness, toughness, dart, tear & puncture resistance) of All PE film structures than the multilayer film containing EVOH benchmark

Summary and Conclusions

- A **quick, semi-quantitative** method to evaluate grease resistance now possible
- *Films containing mixed materials* (e.g. EVOH, nylon) provide good grease resistance, but are **non-recyclable and costly**
- Single site catalyzed bimodal sHDPE resins can provide **effective grease resistance** in multilayer PE films
- Inclusion of single site bimodal sHDPE and sLLDPE resins into grease resistant films provides **numerous design opportunities**
- All PE grease resistant films can be made to have:
 - **excellent physical properties**
 - **easy recyclability**
 - **cost effectiveness**

Acknowledgements

Thanks are due to the co-authors of this paper:

Bronwyn Gillon, Barney Quong and Dan Falla



Thank you

Presented by:
Shivendra Goyal
Shiv.Goyal@novachem.com

© 2016 NOVA Chemicals - All rights reserved.

The information contained herein is provided for general reference purposes only. By providing the information contained herein, NOVA Chemicals makes no guaranty or warranty and does not assume any liability, with respect to the accuracy or completeness of such information, or product results in any specific instance, and hereby expressly disclaims any implied warranties of merchantability or fitness for a particular purpose or any other warranties or representations whatsoever, expressed or implied. Nothing contained herein shall be construed as a license to use the products of NOVA Chemicals in any manner that would infringe any patent. Nothing herein shall be copied, reproduced, distributed or otherwise used without the express written permission of NOVA Chemicals.



NOVA Chemicals is a registered trademarks of NOVA Brands Ltd.; authorized use/utilisation autorisée
SCLAIR® and SURPASS® are registered trademarks of NOVA Chemicals Corporation in Canada and
of NOVA Chemicals (International) S.A. elsewhere; authorized use/utilisation autorisée.



NOVA Chemicals® | Polyethylene